

# centerline

by **HOBART**

CDH/CDL



SCAN TO WATCH MENU PROGRAMMING VIDEO

CUH/CUL



## PROGRAM SETTINGS – Access Changing Parameters

1. Press Menu Button 

2. **EXIT MENU** – OPEN door and close

**00** = Extended Wash – 3-6 minute limit



**01** = Cycle Count – Counter reading has 6 digits (012345 cycle)



For CUH, CUL, CDL & CDH Models equipped with internal chemical pumps

**02** = Detergent Dispensing – 0.0-20.0g/l



**03** = Prime Detergent Pump – Repeat as needed to prime the line



**04** = Rinse Aid Dispensing – 0.0-2.0g/l



**05** = Prime Rinse Aid Pump – Repeat as needed to prime the line



## For CUL & CDL Models Only

### 06 = Sanitizer Dispensing – Range can be 0-100%



### 07 = Prime Sanitizer Pump – Repeat as needed to prime the line



### 08 = Temperature Label (°F/°C)



## For CDH Model Only

### 09 = Chemical Pump Control



Setting	Chemical Pump Control Configuration
0	Internal chemical dosing pumps and external chemical signals disabled
1	Control of internal chemical dosing pumps enabled
2	Control signals for external chemical supply enabled

### 13 = Software Version / Machine Program

